



## Unverified compatible Android Devices

To find the model on your Android device go to Settings > About phone or About tablet.

Babolat POP is compatible with most devices equipped with Bluetooth 4.0 (BLE) and running Android 4.3 or later. The app should be compatible with all Android devices listed above. Non listed devices might be compatible as well.

If you need more information on whether your device can use Babolat POP, please feel free to contact our customer service.

Brand	Model	OS Required	Compatibility
Acer	Liquid Jade S	Android 4.3+	✓
Alcatel	One Touch Idol 2S	Android 4.3+	✓
Archos	59 Xenon	Android 4.3+	✓
Asus	Zenfone 2	Android 4.3+	✓
Caterpillar	B15Q	Android 4.3+	✓
Caterpillar	S50	Android 4.3+	✓
Fujitsu	Arrows NX	Android 4.3+	✓
HTC	Desire 610	Android 4.3+	✓
HTC	Desire 816	Android 4.3+	✓
HTC	Desire 510	Android 4.3+	✓
HTC	HTC J butterfly	Android 4.3+	✓
HTC	One M7	Android 4.3+	✓
HTC	One M8	Android 4.3+	✓
HTC	One M9	Android 4.3+	✓



## Unverified compatible Android Devices

Brand	Model	OS Required	Compatibility
HTC	One Max	Android 4.3+	✓
HTC	One mini	Android 4.3+	✓
HTC	One mini 2	Android 4.3+	✓
Kyocera	Digno U	Android 4.3+	✓
Kyocera	Infobar A03	Android 4.3+	✓
Kyocera	Torque G01	Android 4.3+	✓
Kyocera	Urbano L03	Android 4.3+	✓
LG	Disney Mobile	Android 4.3+	✓
LG	F70	Android 4.3+	✓
LG	G2	Android 4.3+	✓
LG	G3	Android 4.3+	✓
LG	G4	Android 4.3+	✓
LG	isai	Android 4.3+	✓
LG	isai FL	Android 4.3+	✓



## Unverified compatible Android Devices

Brand	Model	OS Required	Compatibility
LG	isai vivid	Android 4.3+	✓
LG	Nexus 4	Android 4.3+	✓
LG	Nexus 5	Android 4.3+	✓
Motorola	Moto E	Android 4.3+	✓
Motorola	Moto G	Android 4.3+	✓
Motorola	Moto X	Android 4.3+	✓
Motorola	Nexus 6	Android 4.3+	✓
Motorola	Droid Turbo	Android 4.3+	✓
Motorola	Droid Ultra	Android 4.3+	✓
Samsung	Galaxy A3	Android 4.3+	✓
Samsung	Galaxy A5	Android 4.3+	✓
Samsung	Galaxy A5	Android 4.3+	✓
Samsung	Galaxy A7	Android 4.3+	✓
Samsung	Galaxy Ace 4	Android 4.3+	✓



## Unverified compatible Android Devices

Brand	Model	OS Required	Compatibility
Samsung	Galaxy Alpha	Android 4.3+	✓
Samsung	Galaxy Camera 2	Android 4.3+	✓
Samsung	Galaxy Core Prime	Android 4.3+	✓
Samsung	Galaxy Grand 2	Android 4.3+	✓
Samsung	Galaxy Grand Prime	Android 4.3+	✓
Samsung	Galaxy Note 3	Android 4.3+	✓
Samsung	Galaxy Note 4	Android 4.3+	✓
Samsung	Galaxy Note Edge	Android 4.3+	✓
Samsung	Galaxy Note 2	Android 4.3+	✓
Samsung	Galaxy S3	Android 4.3+	✓
Samsung	Galaxy S4	Android 4.3+	✓
Samsung	Galaxy S4 mini	Android 4.3+	✓
Samsung	Galaxy S5	Android 4.3+	✓
Samsung	Galaxy S5 mini	Android 4.3+	✓



## Unverified compatible Android Devices

Brand	Model	OS Required	Compatibility
Samsung	Galaxy S6	Android 4.3+	✓
Samsung	Galaxy S6 Edge	Android 4.3+	✓
Samsung	Galaxy Tab 4	Android 4.3+	✓
Samsung	Galaxy Xcover 3	Android 4.3+	✓
Sharp	Aquos Crystal	Android 4.3+	✓
Sharp	Aquos Zeta	Android 4.3+	✓
Sharp	Aquos Xx	Android 4.3+	✓
Sony	Xperia E1	Android 4.3+	✓
Sony	Xperia E3	Android 4.3+	✓
Sony	Xperia M2	Android 4.3+	✓
Sony	Xperia M4 Aqua	Android 4.3+	✓
Sony	Xperia T2 Ultra	Android 4.3+	✓
Sony	Xperia Z Ultra	Android 4.3+	✓
Sony	Xperia Z1	Android 4.3+	✓



## Unverified compatible Android Devices

Brand	Model	OS Required	Compatibility
Sony	Xperia Z1 Compact	Android 4.3+	✓
Sony	Xperia Z2	Android 4.3+	✓
Sony	Xperia Z3	Android 4.3+	✓
Sony	Xperia Z3 Compact	Android 4.3+	✓
Sony	Xperia ZL2	Android 4.3+	✓
Sony	Xperia A2	Android 4.3+	✓
Sony	Xperia Z1	Android 4.3+	✓
Sony	Xperia Z2	Android 4.3+	✓
Sony	Xperia Z4	Android 4.3+	✓
Wiko	Goa	Android 4.3+	✓
Wiko	Lenny	Android 4.3+	✓
Wiko	Wax	Android 4.3+	✓
Xiaomi	Redmi 2	Android 4.3+	✓

*Last updated: 10/11/2015*